


36-Pin (20 + 16 Pins) connector, AMP 175977-2

No.	FUNCTION	No.	FUNCTION
1	SPEED INPUT	11	BATTERY CHARGE
2	TACHO INPUT	12	DOOR OPEN
3	Variant AT : AT SIGNAL	13	ANTI THEFT
4	GAS PWM	14	BRAKE
5	CNG PWM	15	OIL PRESSURE
6	TURN LEFT	16	CHECK ENGINE
7	STOP	17	ESP
8	AMBIENT TEMP	18	SEAT BELT
9	TEMP INPUT	19	PAB DEACT
10	TURN RIGHT	20	BRAKE PAD WEAR
21	AIR BAG	29	PGND
22	IMMOBILIZER	30	ILL(+)
23	HIGH TEMP	31	DIAGNOSIS
24	—	32	FRONT FOG
25	SPARE 1	33	ANTI LOCK
26	REAR FOG	34	LOW BEAM
27	BATTERY	35	IGNITION
28	FGND	36	SGND



8-Pin Connector, AMP 174971-2

No.	FUNCTION	No.	FUNCTION
1	CNG	5	FUEL INPUT
2	CATALITY CONVERTER	6	CRUISE CONTROL
3	HIGH BEAM	7	—
4	ABS/EBD	8	—